

Care and Maintenance Guide for Powder Coated Metal Products:

Care and Maintenance:

- Regular cleaning is crucial for maintaining the aesthetic qualities and extending the lifespan of powder-coated finishes.
- Clean surfaces using warm water and a mild detergent with a soft cloth, sponge, or natural bristle brush.
- Avoid using abrasive materials or chemicals that could damage the coating.
- Periodically inspect for scratches, nicks, and other damage, especially on high-wear surfaces.

Frequency of Maintenance:

- In urban environments, an annual cleaning is typically sufficient.
- Certain areas may require more frequent maintenance.

Minor Repair:

- Minor repairs for small localized chips and blemishes on powder-coated surfaces can generally be done in place.
- Clean the damaged area with a solvent-based degreaser, then abrade with abrasive paper and wipe clean.
- Apply a thin coat of suitable primer, followed by a matching top coat applied by brush or spray.
- Contact us to ensure compatibility between original finishes and repair materials.
- For significant damage exposing the metal, contact us for repair instructions.

By following these guidelines, you can ensure the longevity and aesthetic appeal of your powder-coated metal products, maintaining their quality for years to come.

Wood Maintenance Guide for Outdoor Furnishings:

Care and Maintenance:

- Monitor wood for the first 6 months after installation to address any rapid color changes caused by weather conditions. Refinish as needed.
- Refinishing every one to two years
- Regular checks help preserve natural characteristics, while refinishing as needed maintains a consistent appearance.
- Reduce splitting or end-checking by applying end sealer wax to ends of boards. Ensure wood is clean before application.
- Wood appearance will change over time, especially if not refinished regularly.

Cleaning:

- Wash furniture with warm soapy water or a mild detergent, avoiding harsh cleaners, and scrub with nylon brush.
- Rinse with clean water and allow wood to dry naturally.

Refinishing:

- To begin, clean all wood surfaces as described above.
- Optionally, you may lightly sand the wood using an orbital sander and appropriate grit sandpaper. After sanding, remove any dust and debris by vacuuming and wiping with a damp cloth. Wash wood with warm soapy water or a mild detergent, avoiding harsh cleaners, and scrub with nylon brush. Rinse with clean water and allow wood to dry naturally.
- Allow wood to dry completely before applying fresh coats of sealant or finish.
- Test sealants, oils, or other products on an inconspicuous area before applying to the entire project.

By following these guidelines, you can ensure the longevity and appearance of your wood outdoor furniture.



Plastic Lumber Maintenance Guide for Outdoor Furnishings:

Cleaning:

- Wash furniture with warm soapy water or a mild detergent, avoiding harsh cleaners or abrasives, and scrub with nylon brush.
- Rinse with clean water and allow to dry naturally.